

Group3
DTM-132
DIGITAL TESLAMETER
with serial communications
USER'S MANUAL

For units supplied with software DTM132 V1.3

GMW

P.O. Box 2578, Redwood City, CA 94064
Tel (415) 368-4884 Fax (415) 368-0816

Group 3 Technology Ltd, 2 Charann Place, Avondale, Auckland 7, New Zealand.
P.O. Box 71-111, Auckland 7. Phone (64)(9)828-3358, Fax (64)(9)828-3357

82010110B

CONTENTS

	page
1. General Description	1-1
2. Specifications of System	2-1
3. Setting Up	3-1
3.1 Introduction	3-1
3.2 Connecting the Hall Probe	3-1
3.3 Connecting the Power Source	3-2
3.4 Internal DIP Switch Settings	3-3
3.5 Analog Output	3-3
3.6 Grounding	3-4
4. Operating Instructions	4-1
4.1 Zeroing	4-1
4.2 Installing the Probe	4-2
4.3 Reading the Field Value	4-3
4.4 Display Modes, Using Front Panel Keys	4-4
4.5 Digital Filtering	4-6
5. Serial Communications Option	5-1
5.1 Fiber Optic Connections	5-1
5.2 Electrical Serial Data Input/Output Connections	5-1
5.3 Serial Board DIP Switch Settings	5-4
5.4 Bit Rate Selection	5-6
5.5 Using the Serial Data Inputs & Outputs	5-7
5.6 Triggered Operation	5-14

LIST OF FIGURES

Fig. 1 Power Input Connections	3-2
Fig. 2 Probe Dimensions	4-3
Fig. 3 RS-232-C Connector & Jumper Locations	facing 5-3
Fig. 4 Send and Receive Jumpers	5-4
Fig. 5 Option Jumpers	5-4
Fig. 6 Location of Serial Board Switches	facing 5-5
Fig. 7 G3CL - Alternative Configurations	facing 5-7

LIST OF TABLES

Table 1 Internal DIP Switch Functions	3-3
Table 2 Analog Output Connector Pin Assignments	3-4
Table 3 G3CL Connector Pin Assignments	5-2
Table 4 RS-232-C Connector Pin Assignments, Terminal Mode	5-3
Table 5 RS-232-C Connector Pin Assignments, Modem Mode	5-3
Table 6 Serial Board DIP Switch Functions	5-5
Table 7 Serial Data Format Switch Settings	5-5
Table 8 Bit Rate Switch Settings	5-6
Table 9 Teslameter Commands - alphabetic listing	5-8
Table 10 Teslameter Commands - listing by function	5-12

1. GENERAL DESCRIPTION

The DTM-132 Digital Teslameter offers precision measurement of magnetic flux densities, with direct digital readout in tesla or gauss. The instruments are light and compact, and the probes are easy to use.

Options provide serial communications (RS-232C and fiber optic) or IEEE-488 interfacing for system applications.

FEATURES

Measures magnetic fields over four ranges up to 3 tesla with polarity indication; resolution up to 1 part in 3,000.

Range selection is manual or by selectable auto-ranging.

Used with special miniature Hall probe - easy to attach to magnet pole or other hardware. Probe holders available as optional accessories.

Precision and temperature specifications include performance of probe.

Probe is calibrated, with field and temperature characteristics stored in memory chip contained in cable plug.

Microprocessor reads probe calibration data stored in probe connector to compute corrected field reading, using cubic spline curve-fitting technique.

Precision is $\pm 0.05\%$.

Temperature coefficient is 100ppm/ $^{\circ}\text{C}$.

Precision is verified against nuclear magnetic resonance (NMR) standard.

Calibration is verified at many field points on every probe, and a printed calibration table is supplied with every probe.

Front panel keys set the display to read the desired field range and to read the peak value of the field using the peak hold function. The keys are also used to reset the peak hold and to zero the system.

Peak hold is implemented digitally, has zero sag.

Digital filtering of the displayed field reading suppresses short-term fluctuations. The filtering characteristic is non-linear; small field variations within a narrow window centered on the currently displayed value are filtered; large field changes are displayed immediately. Filter window and time-constant may be changed by remote command. Filtering is controlled by an internal switch.

With digital communications, the DTM-132 can deliver 30 readings per second.

Two digital communication options: serial (RS-232C and fiber optic) and
IEEE-488 General Purpose Interface Bus.

With the serial option, a single teslameter may be connected to standard RS-232C equipment, or up to 32 units may be interconnected on Group 3 Communication Loop (G3CL) and driven from computer or terminal.

Fiber optic ports duplicate functions of RS-232C signals, for electrical noise immunity and voltage isolation. Fiber optic links may be up to 25 meters in length, using Hewlett-Packard HFBR-3500 series fiber optic cables.

The IEEE-488 option fully supports all relevant GPIB functions and commands, including full talker-listener capability, serial and parallel polling, service request, and talker-only.

ASCII control commands are accepted to modify the output data format, to change the rate of data transmission or to request transmission of a single field reading. Other commands select the field range, select and peak hold functions, turn on and off digital filtering and modify the filter characteristics. System status may be determined remotely.

The system can be operated in triggered mode where field measurements by one or more teslameters are triggered in synchronism with each other by external command.

Internal switches select serial data format and baud rate, device address, string terminators, filtering, field units in gauss or tesla, data format, service request action, EOI action, and perform system reset.

An analog output gives instantaneous field value (0 to 9 kHz).

Model variations are available without display and keys for true 'black box' magnetic-field-to-computer interfacing.

A panel mount model with display is available.

2. SPECIFICATIONS OF SYSTEM

Specifications of DTM-132 with LPT-130 Hall Probe.

Measurements	magnetic field density in tesla or gauss
Field ranges	0.3 0.6 1.2 3.0 tesla full-scale, 3 6 12 30 kilogauss full-scale, with polarity indication and selectable autoranging maximum calibrated field ± 2.2 tesla, ± 22 kilogauss
Resolution	1 in 4000 of full-scale, 12-bit digitization 0.5 millitesla (5 gauss) on 3.0T range 0.2 millitesla (2 gauss) on 1.2T range 0.1 millitesla (1 gauss) on 0.6T range 0.05 millitesla (0.5 gauss) on 0.3T range
Precision	$\pm(0.05\%$ of reading + 2 x resolution) at 25°C
Temperature stability	calibration: ± 100 ppm of reading/°C max. zero drift: $\pm(10$ microtesla + 0.1 x resolution)/°C max. add -3ppm/°C for each meter of probe cable
Time stability	$\pm 0.1\%$ max. over 1 year
Measurement rate	30 measurements per second
Display rate	10 display updates per second
Response time	Full-scale change of displayed field reading settles to within specified resolution in less than 0.2 second (filtering off - see below)
Peak hold mode	displays maximum field since mode entered or reset peak hold is implemented digitally with zero sag or decay
Display	7-character 7-segment alphanumeric display for numerical values and messages
Indicators	8 back-lit legends showing: 0.3, 0.6, 1.2, or 3.0 tesla range selected, peak hold mode on, digital filtering on, tesla/gauss field units
Keys	2 keys for range selection, access to peak hold display, zeroing field display, peak hold reset
Digital filtering	field value filtering smooths out small fluctuations in the reading; large, rapid field changes are not filtered; internally switch selected.
On-board switches	digital filtering on/off, autoranging on/off, setting units (tesla or gauss), system reset

Analog output	instantaneous field analog: full-scale output: $\pm 3V$ nominal source impedance: 1000ohm zero offset: $\pm 10mV$ max. accuracy: $\pm 5\%$ residual noise: 0.5mV peak approx. bandwidth: 9kHz at -3dB, rolloff 3-pole 60dB/decade
Power source	9 to 12 V 900 mA ac/dc; ac input plug pack supplied
Enclosure	aluminum, 217 x 125 x 50 mm, textured finish, light tan color, tilt stand fitted to bench models
Ambient field	Maximum operating field for electronics package: 10 millitesla with single-range probe, 0.5 millitesla with multi-range probe.
Temperature range	0 to 50°C operating Absolute maximum temperature of probe 60°C
Instrument weight	1.2 kg
Shipping weight	2.5 kg
Probe	transverse type, LPT-130 probe head 13 x 10.5 x 2.5 mm standard cable length: 2 meters

Additional specifications with communication options

Digital interfacing	serial option: RS-232C and fiber optic; parallel option: IEEE-488 General Purpose Interface Bus
System orientation	Group 3 Communication Loop (G3CL) using serial ports, simple loop for 32 devices, no multiplexer required; GPIB with IEEE-488 option.
Digital data format	ASCII input commands and output responses
Commands	requests for field values; setting and inspection of display and control modes; field measurement triggering; entry of numerical values; setting units, output data format, and filter characteristics; test commands.
Output responses	field value in tesla or gauss followed by optional T or G and carriage return/line feed; numerical and system status; data requested by commands; messages.
Serial bit rate	16 standard rates, switch selected, 50, 110, 134.5, 150, 200, 300, 600, 900, 1050, 1200, 1800, 2000, 2400, 4800, 9600, 19200 baud.
Fiber optic cable	Hewlett-Packard HFBR-3500, 25 meters max.

3. SETTING UP

3.1 INTRODUCTION

This chapter provides instructions for the basic operation of all members of the DTM-132 digital teslameter family and their companion LPT-130 and LPT-230 series Hall probes. If your teslameter is a DTM-132-S (serial communications option) or DTM-132-G (IEEE-488 option), a later chapter will describe the use of the relevant digital communications features. For a summary of all current members of the product family, see page 2-3.

Users of teslameters without the front panel display and keys should ignore sections of this manual referring to these features. All other aspects of operation are identical.

Before using your DTM series teslameter for the first time, please read through sections 3.2, 3.3, 4.1, 4.2, and 4.3 of this manual. This will give a quick introduction to basic operation of the instrument.

3.2 CONNECTING THE HALL PROBE

Before handling the probe, please read section 4.2, page 4-2.

Your DTM-132 is used with a Group 3 LPT-130, LPT-230, MPT-130, or MPT-230 series Hall probe. The probe may be one supplied with your teslameter, or it may have been obtained separately. In any case, calibration is preserved when probes are exchanged between instruments.

All LPT and MPT series probes will operate with all DTM series instruments. However, in order to obtain the specified performance, only 130 and 230 series probes should be used with a DTM-132. Other 30 series probes suitable for use with the DTM-132 may be introduced in the future.

The standard probe cable length is 2 meters. Probes with non-standard cable lengths may be ordered from your Group 3 supplier.

With the DTM-132 unpowered, plug the probe connector into the instrument. The pin side of the plug is inserted into the large opening in the rear of the teslameter, with the plug's label uppermost when the instrument is standing right way up. It is easy to find the correct mating position for the plug, and then push it fully home, but if any difficulty is experienced at first, remove the DTM's top cover by loosening the central screw and lifting the cover off. Now it is possible to see when the plug is centrally located and its overhang slides over the card-edge receptacle, ensuring that its pins engage correctly. Tighten the connector retaining screws finger tight. The teslameter should always be used with both covers attached.

If the probe connector is inserted or withdrawn with power on, no damage will be done, but sometimes the instrument's processor will enter an invalid mode of operation which can only be cleared by removing and re-applying power. Therefore, always power-down before connecting or disconnecting the probe.

When a probe is not connected to the DTM, the display reads "noProbE".

3.3 CONNECTING THE POWER SOURCE

All teslameter versions, except for the L option, are supplied with a plug-pack. Connect the plug-pack to a convenient ac power source, first checking the voltage marked on the plug-pack, and insert the cable connector into the power receptacle on the DTM rear panel.

Instead of the plug-pack, the unit can be powered by any floating source of ac or dc (either polarity), 9 to 12 volts, capable of supplying 800 milliamperes average current. AC sources should be capable of 1.6 amps rms. The cable connector required for power connection to the DTM is generally available from electronics parts suppliers.

The L option will accept mains power input.

Access to the power input terminals of the L option is obtained by taking off the orange cover; remove the 3 fixing screws to release the cover.

Use 3-conductor power cord. For safety from electrical shock it is essential to provide a reliable ground connection to the DTM case. Make sure the ground wire is connected as shown in Fig. 1. Strip about 60 mm (2.5 in) of outer jacket from the cord, and strip 5 mm (3/16 inch) of insulation from the 3 wires. Pass the cord through the grommetted hole in the cover. Loosen the screw securing the cable clamp and pass the cord through the clamp. Tighten the clamp on the outer jacket. Terminate the wires and fit links according to the supply voltage as set out in Fig. 1 below.

Replace the orange cover, making sure that wires are not pinched in the process. For safety reasons, do not operate the unit with the cover off.

Note that input power protection is provided by a thermal fuse wound into the power transformer. This fuse will open in the event of transformer overheating rather than on excess current. The power input must be connected as shown to include the thermal fuse in the circuit correctly. If a fault causes




Fig. 1. Power Input Connections

transformer overheating and subsequently the fuse opens, the transformer must be replaced with the genuine Group 3 part.

If desired, the wiring may be protected by installing an external fuse in the ac power feed. Suggested fuse ratings are 200 mA for 115 volts, or 100 mA for 208 and 230 volt operation.

When the unit is first powered up, the display shows "Group 3" for 2 seconds before field measurements appear.

If the Hall probe is not plugged in, the field reading display is replaced with "noProbe".

3.4 INTERNAL DIP SWITCHES

The main circuit board, under the top cover of the DTM-132, has a set of four DIP switches. The switch functions are listed in Table 1 below. For access to the switches, loosen the central screw and lift the cover off.

switch	function	OFF	ON
1	digital filtering	disabled	enabled
2	no function	MUST BE OFF	
3	no function	MUST BE OFF	
4	field units	tesla	gauss

Table 1. Internal DIP Switch Functions

The functions of switches 1 and 4 are described in full in section 4. The switches are scanned once a second, so the effects of changed settings can be observed immediately.

Note that switches 2 and 3 must be OFF, otherwise the teslameter will not operate correctly.

3.5 ANALOG OUTPUT

An analog output signal is available at the rear of the teslameter. This output is the Hall probe signal amplified to 3 volts full-scale, and gives an indication of the instantaneous field value from dc to 9kHz (-3dB), with a roll-off of 60dB/decade above 9 kHz. Field direction is indicated by the output voltage polarity. There is a small zero offset of 10 millivolts maximum, arising from the probe zero-field output and amplifier offsets. The output impedance is 1000 ohm with a 1nF capacitor to common for noise filtering.

The cable connector required is a Molex receptacle type M5051-2 fitted with M2759 terminals. Pin assignments are given below.

The analog output is not corrected for linearity errors.

<u>pin</u>	<u>signal</u>
1	ground
2	dc output

Table 2. Analog Output Connector Pin Assignments.

3.6 GROUNDING

All parts of the teslameter case are connected together to form an integral electric shield around the circuitry inside. The internal circuitry is not connected to the case. Circuit common and the case are electrically isolated from each another.

For electrical safety, the case of the L version must be grounded through the third wire of the power input cord.

Unlike the main instrument case, the Hall probe connector is connected to circuit common. Do not ground the connector.

4. OPERATING INSTRUCTIONS

4.1 ZEROING

The DTM-132 digital teslameter has very stable zero field readings. Nevertheless, it is good practice to zero the instrument on all ranges immediately prior to making critical field measurements. The zeroing process takes out residual zero errors in the Hall probe and the instrument's preamplifier "front-end".

Zeroing is mandatory if a different probe is to be used since the instrument was last zeroed. You should also zero the instrument when using it for the first time.

Before zeroing the system, connect the probe and apply power as described in sections 3.2 and 3.3. Allow 30 minutes for the instrument and probe to stabilize.

For absolute zeroing, place the probe in a zero-field region, either in a zero field chamber or inside a suitable magnetic shield, so that the probe is shielded from the earth's magnetic field and other stray fields.

If desired, a relative zero setting may be done; the instrument is zeroed after the probe is placed in its measurement position. Thus any ambient field is automatically subtracted from subsequent measurements. The probe should not be moved once zeroing is complete. About 5% of full-scale may be zeroed out without reducing full-scale span below specification.

The zero field reading is affected slightly by the presence of metal against the probe's back surface. If the probe is to be used clamped to a metal surface, or in a probe holder, it should be zeroed in the same situation.

Ambient temperature also has a slight effect on the probe zero. The probe should be zeroed at a temperature as close as possible to the temperature during service.

If the teslameter is set for autoranging (see section 3.4 on page 3-3), zeroing is implemented simply by momentarily pressing both keys together. The display will flash "ZEro" while the teslameter cycles through all four ranges in turn, waiting for each range to stabilize before zeroing it. The whole process takes about 10 seconds. The range indicators show which range is selected. If a single-range probe is connected, only the one range will be selected and zeroed.

If autoranging is disabled, each range must be manually selected and zeroed. A range is selected by pressing the RANGE key. The four range indicators show the selected range. The RANGE key is used to select the ranges in turn in the sequence 0.3, 0.6, 1.2, and 3.0 tesla. If a single-range probe is in use, the RANGE key will have no effect.

The zeroing process is implemented by pressing and releasing both keys together. The display will read "ZEro" for a moment, indicating that zeroing has occurred.

The zeroing process should now be repeated for all the remaining ranges. Press the RANGE key to select another range, and zero this range by pressing both keys together, as above. After changing ranges, wait 1 or 2 seconds before zeroing. Continue until all the ranges have been zeroed.

Once the zeroing process has been completed, the internal processor will apply the appropriate correction to whichever range is selected.

Zero offsets calculated during the zeroing process are stored in non-volatile memory, and are retained while the power is off. Therefore the teslameter does not need re-zeroing simply because it has been powered down.

4.2 INSTALLING THE PROBE

Group 3 Hall probes are built to be as robust as possible for a small, precision device. However, it is most important that certain precautions be taken when handling and installing probes so that they are not damaged or destroyed, and to preserve their accurate calibration.

Mount the probe head so there is no pressure which will tend to bend or depress its ceramic rear surface. If the probe head is clamped, make sure the surface in contact with the ceramic is flat and covers the whole of the ceramic surface. Do not apply more force than is required to hold the probe in place. Any strain on the ceramic will alter the probe's calibration, and excessive force will destroy the Hall element inside.

When the probe head is mounted, the cable should be clamped firmly nearby so it cannot be torn away from the probe head if accidentally pulled. The flexible section adjacent to the probe head can be carefully folded to allow the cable to come away in any direction, but avoid repeated flexing of this section.

Keep the cable out of the way of foot traffic. Do not pinch the cable, or drop sharp or heavy objects on it. A severed cable cannot be re-joined without altering the probe's performance, and requires factory repair and re-calibration.

The LPT-130 and LPT-230 probes can be fitted to a Group 3 probe holder part no.17000049. The holder protects the probe and provides additional cable strain relief. Alternatively, the probe can be clamped using the machined detail in each side of the metal cap.


The probe will measure the component of the field which is normal to the flat surface of the probe case. The point of maximum sensitivity is marked by a target printed on the top of the probe case. A positive indication will be obtained when the magnetic field vector enters this side of the probe. The target represents the tail of the vector arrow. Magnetic field convention is that field lines are directed from an N pole to an S pole.

Fig. 2 gives the dimensions of LPT-130 and LPT-230 probes, and shows the position of the most sensitive point.

If the exact direction of the magnetic field is unknown, its magnitude can be

measured by putting the DTM in the peak hold mode, and slowly rotating the probe. As the probe turns and the measured field rises and falls, its maximum value is held on the display. See section 4.4.2b on page 4-4.

LPT-130 and LPT-230



Dimension X is the distance from the rear ceramic surface to the sensitive element of the Hall probe. The center of the sensitive area is marked on the probe cap to a tolerance of ± 0.3 mm.

Fig. 2. Probe Dimensions.

4.3 READING THE FIELD VALUE

The field value is read directly off the display. A negative sign indicates that the field direction is opposite to that described in section 4.2.

The DTM-132 has autoranging capability, and powers up in this mode. Autoranging can be enabled or disabled using the front panel MODE key. See section 4.4 on page 4-4.

If autoranging is enabled, the teslameter will change to the next range up when the displayed reading reaches 105% of full scale on the current range. The next range down will be selected when the reading drops to 95% of full scale on the next lower range.

If autoranging is disabled, the operator must select the most appropriate range. For maximum resolution, select the lowest range which will display the

field value. See sections 4.1 and 4.4 for range selection instructions. If the field exceeds about 106% of full-scale, the message "o'rAnGE" will be displayed. Change to a higher range by pressing the RANGE key until the message clears.

The field may be displayed in tesla or gauss, with the appropriate indicator showing the units in use. To change the units, remove the top cover and operate switch 4. See section 3.4 on page 3-3.

4.4 DISPLAY MODES, USING THE FRONT PANEL KEYS

4.4.1 The Keys.

Two front panel keys are used to control the teslameter.

The MODE key, used on its own, switches the instrument between its operating modes, field and peak hold field, and auto-ranging. Pressing the MODE key brings up the operating modes in the following sequence:

field display auto-ranging (power-up default mode)
peak hold field manual range change
peak hold field auto-ranging
field display manual range change

Auto-ranging is indicated by a flashing decimal.

Hold mode is indicated by the HOLD indicator.

The RANGE key selects the range without changing the display mode.

If a single-range probe is in use or if auto-ranging is enabled then the range cannot be changed using this key.

The keys are pressed together to zero the display. The keys must be pressed close to simultaneously for zeroing to take place.

The same action is used to reset the display in the peak hold mode.

4.4.2 Operating Modes.

a. Field display.

The teslameter powers up in auto-range, indicated by a flashing decimal. Four ranges, 0.3, 0.6, 1.2, and 3.0 tesla full-scale, are selected automatically in auto-range, or manually in sequence by pressing the RANGE key when auto-ranging is off.

Four range indicators show the range in use.

With 230 probes, divide the full-scale range indicator by 10.

With all probes, the display shows the true field value. A minus sign is added to indicate reverse polarity fields.

Press the keys together to zero the display. The display shows "ZZero".

In auto-range, all ranges are zeroed in turn, taking 10 seconds.

Field reading is filtered if selected by the internal switch - see p.3-3.

The FILTER indicator shows when filtering is enabled.

b. Peak hold display, ranges as above.

Displays maximum field measurement taken, either polarity,
since entering the mode, or since last reset.
"HOLD" indicator shows peak hold mode is operating.
If filtering is on, the filtered field value is held.
Reset is performed by pressing both keys together.
The peak value is also reset if the field polarity changes.

4.4.3 No Probe, Over-range, and Overflow Display Messages

a. No Probe.

The message "noProbE" is displayed if the Hall probe is disconnected from the instrument. While the message is visible, all key functions are disabled.

b. Over-range.

The message "o'rAnGE" appears if the field to be measured exceeds the instrument's input capacity.

To clear the over-range message, select a higher range or reduce the magnetic field at the probe, or both if necessary.

During over-range, all key operations are locked out, except for range selection.

If autoranging is selected, steady over-ranging will occur only when full-scale of the highest range is exceeded.

If a single-range probe is in use, no range changing can occur.

c. Overflow.

The message "o'FLo" is displayed if the computed value of the field reading exceeds the capacity of the display.

In overflow, the instrument is not over-ranged, but rather the computed reading is too large to be displayed. However, if over-ranging occurs at the same time as overflow, then the over-range message is displayed preferentially.

If the overflow message appears on a DTM-132, please contact the supplier of the teslameter.

d. Error 1.

This indicates that the main circuit board has no calibration eeprom chip and cannot be used with this software version.

4.5 DIGITAL FILTERING

The teslameter software includes a digital filtering algorithm which may be enabled turning on internal DIP switch 1. See page 3-3. Filtering is useful for smoothing out small fluctuations in the field reading. When filtering is enabled, the FILTER indicator is lit.

In order to speed up the response to large field changes when filtering is on, a window is set to define a band about the current displayed field value. Filtering will only occur while the unfiltered field value remains within the window. If the field value changes rapidly enough, the filtered field reading will not be able to follow fast enough to keep the unfiltered value within the window, and filtering is temporarily disabled. This allows the field reading to follow large rapid field changes, while providing good filtering of constant or slowly varying fields.

The default window width is 20 resolution increments on each side of the displayed field reading, for a total window width of 40 increments.

The digital filter performs the following computation:

$$F(\text{new}) = F(\text{old}) + \frac{F - F(\text{old})}{J},$$

where $F(\text{old})$ is the previous field reading display
 $F(\text{new})$ is the updated field reading display
 F is the most recent unfiltered field reading
 J is the filter factor.

The effective time constant of the filter is dependent upon both the rate at which field measurements are made and the value of J , according to the formula:

$$T = P / \{\ln[J/(J-1)]\}$$

where T is the filter time constant
and P is the period between field measurements.

Field measurements are made at a fixed rate of 30 per second, so $P = 0.033$. With the default value of $J = 8$, the filter time constant is 0.25 seconds. This gives a cut-off frequency in the displayed field reading of 0.64Hz.

5. SERIAL COMMUNICATIONS OPTION

5.1 FIBER OPTIC CONNECTIONS

The DTM-132-_S has facilities for communicating with external devices, such as computers or terminals, using its serial ports. The teslameter may also be set up to relay communications through other compatible Group 3 devices, using the Group 3 Communication Loop. See section 5.5.

There are three bi-directional ports, two using standard RS-232C signals, the third employing fiber optics. In electrically noisy environments, or where ground loops could be troublesome, or if a voltage gradient must be traversed, it is advisable to use fiber optics for the serial data link. The teslameter's fiber optic ports accept Hewlett-Packard HFBR-3500 series fiber optic cables up to 25 meters (80 feet) in length.

Fiber optic cables are fitted with a blue connector at one end and a gray connector at the other. Although functionally identical, the colors make it easier to keep track of cable routing when connecting up a system. The convention is to use gray at send ports and blue at receive ports.

To connect the cables, simply push the connector in through the appropriately labelled hole in the teslameter's rear panel. The connector will snap into place. To disconnect, give the cable a gentle tug. Loose cable ends should be protected from dirt and scratching.

5.2 ELECTRICAL SERIAL DATA INPUT/OUTPUT CONNECTIONS

Serial data connections to the teslameter can be made electrically in two ways, as alternatives to the fiber optic method described in the previous section:

5.2.1 The G3CL Ports

The two 4-way Group 3 Communication Loop connectors, one each for send and receive, provide an electrical alternative to the fiber optic ports, and handle the same data. Signal levels are equivalent to RS-232C levels. RS-232C handshake signals are not present at these ports.

The G3CL ports allow serial connections to be made using a simple twisted pair or coaxial cable for each data direction, and avoid consideration of handshake signals if these are not required in the application.

Connection to the G3CL ports requires two Molex receptacles type M5051-4 with M2759 crimp terminals. Pin assignments are given in Table 3 below. The RS-232C standard allows cable lengths of up to 50 ft, but in practice longer cables will work reliably, particularly at the lower bit rates. Connection is made through the labelled opening in the teslameter's rear panel.

In the device at the send port, pin 2 (common) is connected to circuit common. However, at the receive port the signal drives an optical coupler without any direct connection to the circuitry. This arrangement avoids ground loops which can inject noise into the link and give rise to transmission errors.

pin no.	use
1	signal active
2	signal common
3	cable shield (optional)
4	not used

Table 3. G3CL Connector Pin Assignments.

5.2.2 The RS-232C Connector

The RS-232C connector is a 26-pin field which can be used to connect the teslameter to a computer, terminal, printer, or other external equipment which can send and receive RS-232C signals. The pin field will connect with a standard 26-way flat cable socket connector, for example 3M type 3399-6000. The pin assignments follow those of the standard 25-way RS-232C connector, starting at pin 1 and omitting pin 26. If desired, an adaptor cable may be used to allow cables with 25D connectors to be plugged in to the teslameter.

In order to avoid the conflicts and confusion which often arise when RS-232C is used to interconnect equipment which cannot be classified strictly as either communications or terminal equipment, the teslameter has been provided with a number of user options in the form of moveable jumpers and wire-wrap posts on the serial board. Thus pins 2 and 3 may be connected to send and receive signals, respectively, or vice versa.

Similarly, a number of the most-used RS-232C handshake signals are provided on the board, and these may be routed to appropriate pins on the connector if desired. But their use is optional. In most cases no active handshaking need be used. Some external equipment may require certain signal lines to be held high for correct operation. These options are provided for (see below).

The teslameter can provide one output handshake signal, RTS, which is asserted high when the unit has data it wishes to transmit.

The teslameter can also accept up to two input handshake signals, CTS and DCD. If CTS is held low by the external equipment, then no data will be transmitted. When low, DCD inhibits and initializes the receive input of the teslameter. DCD must be high to allow the unit to accept incoming data. If these inputs are not connected to the RS-232C pin field, the relevant pins must be tied to +5 volts on the serial board, using the jumpers provided.

The handshake signals can be used only when the teslameter is connected directly through its RS-232C connector to an RS-232C compatible device. When several Group 3 devices are arranged in a loop using the Group 3 Communication Loop ports, RS-232C handshaking cannot be used. CTS and DCD must be tied high in this case.

Table 4 below gives the pin assignments and signal names when the teslameter is configured as a Data Terminal Equipment (DTE). This will be referred to as terminal mode.

pin no.	RS-232C signal name	signal direction	connection in teslameter
1	protective ground		instrument case
2	transmit data	output	TX
3	receive data	input	RX
4	request to send	output	*RTS or +5V
5	clear to send	input	*CTS or open
6	data set ready	input	*DCD or open
7	common		circuit common
8	carrier detect	input	*DCD or open
20	data terminal ready	output	*+5V

* option according to requirements of external equipment.
Note: connect CTS and DCD to +5 volts if not otherwise used.

Table 4. RS-232C Connector Pin Assignments, Terminal Mode.

The unit can also be set up to behave like a Data Communications Equipment (DCE), for example a modem. The instrument is then said to be in modem mode. See the RS-232C connector pin assignments for modem mode below in Table 5.

pin no.	RS-232C signal name	signal direction	connection in teslameter
1	protective ground		instrument case
2	transmit data	input	RX
3	receive data	output	TX
4	request to send	input	*DCD or open
5	clear to send	output	*+5v or pin 4
6	data set ready	output	*RTS or +5V
7	common		circuit common
8	carrier detect	output	*RTS or +5V
20	data terminal ready	input	*CTS or open

* option according to requirements of external equipment.
Note: connect CTS and DCD to +5 volts if not otherwise used.

Table 5. RS-232C Connector Pin Assignments, Modem Mode.

Fig. 3 shows the location of the RS-232C pin field, moveable jumpers and wire-wrap posts on the serial board.

For terminal mode, the send and receive (T/M) jumpers should be pushed onto the square posts lined up parallel with the long side of the circuit board. In modem mode, the jumpers are set at right-angles to the above. See Fig. 4 next page.




Fig. 4. Send and Receive Jumpers (a) Modem Mode, (b) Terminal Mode.

The option 1 and 2 jumpers configure the relationship between the RS-232C connector and the G3CL ports. For single device systems, option 2 should be selected. Refer to Fig. 5 below. Section 5.5 describes the use of the option jumpers in setting up the alternative G3CL arrangements.




Fig. 5. Option Jumpers (a) Option 1 (b) Option 2.

Fig. 3 also indicates the positions of the wire-wrap posts on which appear the RTS, CTS, and DCD signals, +5 volts and ground, and posts which connect to RS-232C connector pins 4, 5, 6, 8, and 20. These pins may be wire-wrapped according to the options set out in Tables 4 and 5. When pins are adjacent they may more easily be connected with push-on jumpers.

5.3 SERIAL BOARD DIP SWITCH SETTINGS

The Serial Board in the teslameter is provided with two sets of DIP switches, allowing the user to set up operation and communications according to system requirements.

To obtain access to the switches, turn the teslameter over and take off the bottom cover by loosening the single central screw. Refer to Fig. 6 for switch locations. Switch functions are as follows:

- S1 8-way DIP switch - sets device address; sets serial data format:
number of data bits, parity, and number of stop bits.
- S2 8-way DIP switch - selects operation mode and communication mode.

Detailed DIP switch settings are given in Tables 6 and 7 below.

The switches are read by the processor once per second, so the effects of changed settings can be observed in real time.

switch	function	switch OFF	switch ON
S1-1	set device address	*adds 0 to address	adds 1 to address
S1-2	set device address	*adds 0 to address	adds 2 to address
S1-3	set device address	*adds 0 to address	adds 4 to address
S1-4	set device address	*adds 0 to address	adds 8 to address
S1-5	set device address	*adds 0 to address	adds 16 to address
S1-6)		
S1-7)serial data format	see Table 7 for encoding format	
S1-8)		
S2-1	transmission mode	on demand only	*every reading sent
S2-2	select terminator	line feed	*carriage return
S2-3	double terminator	disabled	*enabled
S2-4	echo commands	echo OFF	*echo ON
S2-5	not used		
S2-6	units symbol	no symbol	*symbol after data
S2-7	not used		
S2-8	not used		

* switch settings when shipped

Table 6. Serial Board DIP Switch Functions.

S1-8	S1-7	S1-6	data bits	parity	stop bits
*OFF	*OFF	*OFF	7	even	2
OFF	OFF	ON	7	odd	2
OFF	ON	OFF	7	even	1
OFF	ON	ON	7	odd	1
ON	OFF	OFF	8	none	2
ON	OFF	ON	8	none	1
ON	ON	OFF	8	even	1
ON	ON	ON	8	odd	1

Table 7. Serial Data Format Switch Settings.

If the system contains only one device, it is recommended that its address be set at 0 (S1-1 through S1-5 OFF). Then the external control device does not need to initiate commands with a device address command.

Also in a single device system, S2-1 can be set ON so the teslameter will transmit field readings continuously at the maximum rate of 30 per second. S2-1 sets continuous transmission only if the device address is 0.

S2-2 selects the character sent as string terminator. S2-3 when ON introduces a pre-terminator character before the final string terminator. The pre-terminator is the character not selected by S2-2. The terminator sequence as selected by S2-2,3 is as follows:

		S2-2	
		OFF	ON
S2-3	OFF	lf	cr
	ON	cr/lf	lf/cr

S2-4 controls the echoing of input commands by the teslameter. If echoing is selected, every command from the external control device is echoed before the response to the command is transmitted. Usually echo is set ON if the 26-way RS-232C port is used, and OFF when using either pair of G3CL ports. If echo is ON in the latter case, the teslameter will transmit each input command twice, first the original command rippling through, then the echoed command. When echo is OFF when the RS-232C port is used, the input command will not be returned to the external control device.

S2-6 when ON adds the field units characters T or G to the transmitted string after the numerical values.

5.4 BIT RATE SELECTION

A 16-position switch is provided on the Serial Board for setting the serial data bit rate (baud). See Table 8 for switch position versus bit rate, and Fig. 6 for the location of the switch. The baud rate must be set to match that of the communicating device.

switch position	baud
0	50
1	110
2	134.5
3	150
4	200
5	300
6	600
7	900
8	1050
9	1200
A	1800
B	2000
C	2400
D	4800
E	9600
F	19200

Table 8. Bit Rate Switch Settings.

5.5 USING THE SERIAL DATA INPUTS AND OUTPUTS

5.5.1 Serial Data Connections

The three bi-directional serial input/output ports at the rear of the teslameter can be used in various ways to connect the device to external equipment for data logging and systems applications. Sections 5.1 and 5.2 give information on making connection to the ports and configuring the signal flow.

In systems containing more than one teslameter or other compatible Group 3 device, the serial data path can be configured in an arrangement called the Group 3 Communication Loop (G3CL). This allows convenient communication of up to 32 devices with a single computer or terminal without the need for a multiplexer.

The G3CL is a communication protocol defining hardware, electrical and fiber optic signal parameters, and a command structure based on the ASCII code. All the commands applicable to the teslameter are defined in Tables 9 & 10 below.

In the G3CL a message from external equipment (computer, terminal, modem etc.) is sent to the first device in the loop. This device retransmits the message to the second, and so on around the loop, until finally the last device sends the message back to the external unit. Thus the system verifies that all devices are active and have listened to the message. See Fig. 7.

Each device is assigned a unique address in the range 0 to 31, as set on the internal switches (see page 5-4). When connected in a loop containing more than one device, the devices must be set by means of an internal switch not to initiate communications themselves. They may only respond to commands from the host unit. In the teslameter, switch S2-1 must be OFF.

All Group 3 devices with serial communication are fitted with fiber optic transmitters and receivers as a standard feature. Fiber optic cabling is particularly valuable when the loop runs in the vicinity of electrically noisy equipment, or when voltage isolation is required. The system uses the Hewlett-Packard HFBR-3500 series fiber optic cables. Individual cable sections between devices may be up to 25 metres in length.

Use a Group 3 model FTR fiber optic to RS-232C adaptor to connect the fiber optic cables to a standard 25-way D-type RS-232C receptacle on your computer or terminal.

Electrical serial data connections to the RS-232C standard are provided on Group 3 serial devices. There are two possible configurations of the loop using electrical signals, as shown in Fig. 7.

One arrangement uses the RS-232 connection between the host equipment and one of the devices on the loop. The rest of the loop is connected via the G3CL ports, either electrical or fiber optic, or a mixture.

The second arrangement uses the G3CL ports on every device. Observe the option jumper settings required as shown in Fig. 7. See Fig. 6, facing page 5-5. Note that the fiber optic and electrical G3CL ports are functionally identical and are completely interchangeable in use.

5.5.2 DTM-132_S Serial Input Commands

The commands which can be used with the teslameter, either as a single unit or in a G3CL of various Group 3 devices, are set out in Tables 9 & 10 below. Table 9 lists the commands in alphabetical order, while Table 10 groups the commands according to function. In order to gain familiarity with the commands, it is recommended that you connect the DTM to a terminal. The commands can then be typed in from the keyboard, and the responses observed on the terminal's screen.

The commands are in the form of one to three ASCII alphabetical characters, in some cases followed by a decimal number represented by n in the table.

All commands expecting a number longer than 1 digit must be followed by a carriage return <cr> character. If no number is entered where one is expected, zero will be entered automatically. A decimal point is not required in whole number entries.

Numerical values entered by commands are retained in non-volatile memory when power is off.

Default values shown below apply after system reset command CTRL X.

Switch-selectable defaults are instated on power-up, reset, and when a switch setting is changed. See sections 3.4 and 5.3.

All teslameter responses start with a space character. Decimal numbers include a decimal point. Some are in exponential format.

If an error message is returned, the complete command must be re-entered.

TABLE 9. TESLAMETER COMMANDS - ALPHABETIC LISTING

command	description
An	Address device n - all following commands are acted on only by the unit of address n (n = 0 though 31) as set on internal switches.
B<text><cr>	ASCII text (7 characters maximum) appears on teslameter display.
B<cr>	Cancel text mode, return to normal display.
Dn	Digital filtering - displayed and transmitted field values are digitally filtered: n = 0, no ; n = 1, yes. Default set by switch 1.
EP	Erase (reset) peak hold field value.
EZ	Erase zero - cancels zero correction on current range.
F	Field - teslameter returns a field value.

TABLE 9. TESLAMETER COMMANDS - ALPHABETIC LISTING - continued

GC	General function Continuous - field is measured continuously at 30 readings per second. This is the power-up default mode.
GV	General function Triggered - field is measured only on V command.
IA	Inspect auto ranging status - returns 0 for OFF, 1 for ON.
ID	Inspect Digital filtering status - returns 0 for OFF, 1 for ON.
IG	Inspect General function - returns C for continuous, V for triggered
IJ	Inspect filter factor - returns filter factor.
IK	Inspect sampling interval - returns interval in seconds between transmitted field values. 0 implies readings sent at maximum rate.
IN	Inspect display mode - returns H for hold display, N for normal.
IR	Inspect Range - returns 0 for most sensitive range through to 3 for least sensitive range.
IY	Inspect window - returns value of window within which digital filtering operates.
IZ	Inspect zero - returns zero correction of selected range.
Jn	Filter factor - enters filter factor n. Default n = 8. Allowed n = 1, 2, 4, 8, 16, 32, 64, 128. Entered values from 2 to 128 are rounded to nearest allowed value. Filtering becomes more severe as n increases.
Kn	Sampling interval - enters interval between output field values. Default n = 0, every reading sent, rate is 30 per second; n = any positive number with 1 decimal place up to 6553.4, time in seconds between transmitted field values.
M	Invoke system Monitor. Enter X<cr> to return to teslameter operation
NH	Display mode: Hold - teslameter display shows peak field value.
NN	Display mode: Normal - teslameter displays instantaneous field value
P	Peak hold field - teslameter returns peak field value. Peak value is always available irrespective of display mode.
Q	Test teslameter front panel display.
Rn	Range selection: n = 0 through 3 selects most sensitive through least sensitive range. Default is least sensitive range, or range of single-range probe. Ignored if teslameter is in auto range mode. Returns error message if single-range probe is in use.

TABLE 9. TESLAMETER COMMANDS - ALPHABETIC LISTING - continued

SA n	Auto Range mode invoked: n = 0, no ; n = 1, yes. Default is autoranging ON.
SE n	Set echo - every character received is echoed by teslameter: n = 0, no ; n = 1, yes.
SM n	Set transmission mode: n = 0, output on request using F command. n = 1, field values transmitted at interval defined by Kn command. Default set by S2-1.
SU n	Set units symbol: T or G after field value, n = 0, no ; n = 1, yes. Default set by S2-2.
SZ n	Set zero - enters zero offset n for the selected range; useful when the teslameter must be zeroed but using Z command is inconvenient; the correct zero offset must be known; can be obtained after Z command by using IZ, and should be noted for future use with SZ.
UFG	Units: field values displayed and transmitted in gauss
UFT	Units: field values displayed and transmitted in tesla
	} Default set by switch 4
V	Triggers field measurement after triggered mode selected by GV.
WA	Returns uncalibrated raw field reading immediately after digitizing.
WE	Like WA except field reading has teslameter's internal calibration applied, but not corrected for probe errors.
WZ	Like WE except field reading is modified by user-entered zero.
Y n	Window - enters n = window within which digital filtering occurs. Maximum n = 255. Default ± 20 resolution increments on current range.
Z	Zero - defines present field value as zero for selected range only.
CTRL B	returns single hex character 0 through F indicating the position of the baud rate selection switch; once the command has been given, changing the switch position does not alter the baud rate until some other command is sent.
CTRL D	returns a 20-bit binary number representing the states of the 4 DIP switches on the main board and the 16 DIP switches on the communications board. 0 = OFF, 1 = ON; once the command has been given, changing the switch position does not alter the baud rate until some other command is sent.
CTRL U	Restarts operating software as if DTM had been freshly powered up.
CTRL X	System reset - all default values & modes reinstated. The message RESET is transmitted.

End of Table 9.

5.5.3 Serial Output Error Messages

The following error messages are transmitted as a result of error conditions:

BAD OR MISSING EEPROM indicates that the main board has no calibration eeprom chip and cannot be used with this software version.

INVALID COMMAND ENTRY indicates that the command entered was illegal.

NUMBER TOO BIG indicates that the number entered in a command was too big.

POSITIVE NUMBER REQUIRED indicates erroneous entry of minus sign.

FRAMING ERROR indicates the wrong number of bits were sent in one or more characters of the last command.

OVERRUN ERROR indicates characters were sent too quickly for the DTM to process. The teslameter contains a fifo buffer which can accept more than 30 command characters in an unbroken stream.

PARITY ERROR indicates a mismatch in parity in one or more characters of the next command to be executed.

If framing, overrun, or parity errors are detected, the command is ignored.

FIXED RANGE PROBE and AUTORANGING indicate an illegal attempt to change range.

The messages NO PROBE, OVERFLOW, and OVERRANGE duplicate the functions of these messages on the DTM display.

5.5.4 Some Examples Using the Commands

With the teslameter connected to a source of serial data as described in sections 5.1 and 5.2, send the character Z to the DTM. This will zero the range currently selected. To check which range is current, send IR to the DTM. The response will be 0 for the 0.3 tesla range, 1 for 0.6T, 2 for 1.2T, and 3 for the 3.0T range. In order to change the range, send R followed by a single numeral as defined above, e.g. R2 will select the 1.2T range, and IR will return 2 to confirm the range selection. Always wait a second or two after a range change before zeroing.

To check which mode the DTM is in, send IG. This will return C for continuous mode or V for triggered mode.

Zero all ranges: R0/ZR1/ZR2/ZR3/Z , where / indicates a 1 to 2 second pause.

If a single range probe is in use, attempts to select another range will return the message FIXED RANGE PROBE.

The command F will return the field value as measured by the selected range.

TABLE 10. TESLAMETER COMMANDS - LISTING BY FUNCTION

COMMUNICATIONS

An	Address - all following commands are acted on only by the unit of address n (n = 0 through 31) as set on internal switches.
Kn	Sampling interval - enters interval between output field values. Default n = 0, every reading sent, rate is 30 per second; n = any positive number with 1 decimal place up to 6553.4, time in seconds between transmitted field values.
IK	Inspect sampling interval - returns interval in seconds between transmitted field values. 0 implies readings sent at maximum rate.
SEn	Set echo - every character received is echoed by teslameter: n = 0, no ; n = 1, yes.
SMn	Set transmission mode: n = 0, output on request using F command. n = 1, field values transmitted at interval defined by Kn command. Default set by S2-1.
SUn	Set units symbol: T or G after field value, n = 0, no ; n = 1, yes. Default set by S2-2.
UFG	Units: field values displayed and transmitted in gauss
UFT	Units: field values displayed and transmitted in tesla
Default set by switch 4	

FIELD VALUES

F	Field - teslameter returns a field value.
P	Peak hold field - teslameter returns peak field value. Peak value is always available irrespective of display mode.
WA	Returns uncalibrated raw field reading immediately after digitizing.
WE	Like WA except field reading has teslameter's internal calibration applied, but not corrected for probe errors.
WZ	Like WE except field reading is modified by user entered zero.

RANGE SELECTION

Rn	Range selection: n = 0 through 3. R3 selects highest range. Default is highest range, or range of single-range probe. Ignored if teslameter is in auto range mode. Returns error message if single-range probe is in use.
SAn	Auto Range mode invoked: n = 0, no ; n = 1, yes. Default is autoranging ON.
IA	Inspect auto ranging status - returns 0 for OFF, 1 for ON.
IR	Inspect Range - returns current range as 0 through 3.

TABLE 10. TESLAMETER COMMANDS - LISTING BY FUNCTION - continued

ZEROING

Z	Zero - defines present field value as zero for selected range only.
IZ	Inspect zero - returns zero correction of selected range.
EZ	Erase zero - cancels zero correction on current range.
SZn	Set zero - enters zero offset n for the selected range; useful when the teslameter must be zeroed but using Z command is inconvenient; the correct zero offset must be known; can be obtained after Z command by using IZ, and should be noted for future use with SZ.

FILTERING

Dn	Digital filtering - displayed and transmitted field values are digitally filtered: n = 0, no ; n = 1, yes. Default set by switch 1.
ID	Inspect Digital filtering status - returns 0 for OFF, 1 for ON.
Jn	Filter factor - enters filter factor n. Default n = 8. Allowed n = 1, 2, 4, 8, 16, 32, 64, 128. Entered values from 2 to 128 are rounded to nearest allowed value. Filtering becomes more severe as n increases.
IJ	Inspect filter factor - returns filter factor.
Yn	Window - enters n = window within which digital filtering occurs. Maximum n = 255. Default ± 20 resolution increments on current range.
IY	Inspect window - returns value of window within which digital filtering operates.

PEAK HOLD MODE

P	Peak hold field - teslameter returns peak field value. Peak value is always available irrespective of display mode.
EP	Erase (reset) peak hold field value ready to acquire new peak value.
NH	Display mode: Hold - teslameter display shows peak field value. NN returns to normal field display.

TRIGGERING

GV	General function Triggered - field is measured only on V command.
V	Triggers field measurement after triggered mode selected by GV.
GC	General function Continuous - field is measured continuously. Cancels triggered mode. This is the power-up default mode.
IG	Inspect General function - returns C for continuous, V for triggered

TABLE 10. TESLAMETER COMMANDS - LISTING BY FUNCTION - continued

DISPLAY

UFG	Units: field values displayed and transmitted in gauss	} Default set by switch 4
UFT	Units: field values displayed and transmitted in tesla	
NH	Display mode: Hold - teslameter display shows peak field value.	
NN	Display mode: Normal - teslameter displays instantaneous field value	
IN	Inspect display mode - returns H for hold display, N for normal.	
B<text><cr>	ASCII text (7 characters maximum) appears on teslameter display.	
B<cr>	Cancel text mode, return to normal display.	
Q	Test teslameter front panel display.	

SYSTEM & TESTING

M	Invoke system Monitor. Enter X<cr> to return to teslameter operation
Q	Test teslameter front panel display.

CTRL B returns single hex character 0 through F indicating the position of the baud rate selection switch. Once the command has been given, changing the switch setting does not change the baud rate until some other command is given.

CTRL D returns a 20-bit binary number representing the states of the 4 DIP switches on the main board and the 16 DIP switches on the serial board. 0 = OFF, 1 = ON. Once the command has been given, changing a switch setting does not alter teslameter operation until some other command is given.

CTRL X System reset - all default values & modes reinstated.
The message RESET is transmitted & display shows rESet.

TABLE 10. TESLAMETER COMMANDS - LISTING BY FUNCTION

5.6 TRIGGERED OPERATION

Triggering allows one or more teslameters to make synchronized field measurements on demand.

The teslameter is set for triggered operation by entering the command GV. This stops continuous sampling of the field value.

To initialize a measurement, enter the command V. This is the only command which is simultaneously obeyed by more than one device on the loop; the V is

To initialize a measurement, enter the command V. This is the only command which is simultaneously obeyed by more than one device on the loop; the V is not to be preceded by an address command; all devices which have been set for triggered operation by the GV command will respond to the V. The new measurement will immediately appear on the teslameter display, and can be read on the serial output by entering the F command.

As a useful diagnostic aid while a system is being set up, the effects of the GV and V commands on the teslameter can be observed directly by removing its top cover and watching the LED nearer the front panel on the analog board. During normal continuous operation the LED will seem to be on continuously but in fact it is flashing 30 times per second in accordance with the field measurement rate. After the GV command the LED will stop flashing. Then each time the V command is given, the LED will flash once. Continuous operation is restored using the GC command.

The following sections describe details of triggered operation.

5.6.1 Automatic transmission of new measurement

When a teslameter is used on its own as the only device in a G3CL, the field measurement triggered by V will then be transmitted immediately if the device has been set for continuous transmission by the SM1 command or if S2-1 is ON with the address set to zero.

If the teslameter has been initialized by the SMO command, or if S2-1 is OFF, or if the device address is not zero, the new measurement will not be transmitted until the F command is entered.

In multi-device systems, each teslameter should be set NOT to send the new reading automatically; each device must be read out individually by addressing it (An) then requesting a field value using F.

5.6.2 Digital filtering with triggered operation

If filtering is ON, then each time a measurement is triggered the filtering algorithm will calculate a new field value for display and transmission, as described in section 4.5.

The effective time-constant will depend on the timing of the V commands.

If the field values obtained on triggering are required to reflect only the field at the time of triggering and not contain any history, then filtering should be turned OFF.

5.6.3 Triggered operation timing

The teslameter starts sampling the field 0.4 to 0.8msec after the V has been received.

Field sampling time is 8.33msec.

After sampling, the value is digitized and computations are done.

The new field value is ready no later than 60msec after the V.
Do not request transmission of the value (using F) sooner than 60msec after the V command, or the old field value may be transmitted.

If the teslameter is set for automatic transmission of the new value, transmission will start 10 to 60msec after the V, depending on the field value.

5.6.4 When the V command is ignored

The V command is ignored by teslameters which have not been initialized for triggering by the GV command.

The V command is ignored by teslameters which have been initialized for triggering, if the command is received while the device is still in the process of making a measurement in response to a previous V command.

5.6.5 Zeroing while in triggered mode

If the teslameter is zeroed, either with the keys or by remote command, while in the triggered mode, a new zero offset will be calculated and stored, using the last field measurement made. The effect of the zero operation will be reflected in the next field measurement, when the V command is given.

To ensure the most accurate zero, it is best to place the teslameter in continuous mode with filtering on, allow time for the display to settle, then give the zero command.

The unit will zero correctly in triggered mode if first the V command is given while the probe is in zero field with filtering off; then the Z command (or pressing both keys together) will zero the instrument.

GROUP 3 TECHNOLOGY LTD

LIMITED WARRANTY

Group 3 Technology Ltd. (hereinafter called the Company) warrants instruments and other products of its manufacture to be free from defects in materials and workmanship that adversely affect the product's normal functioning under normal use and service for a period of one year from the date of shipment to the purchaser.

The obligation of this warranty shall be limited to repairing or replacing, at the discretion of the Company and without charge, any equipment which the Company agrees is defective as set out above within its warranty period.

The Company will reimburse lowest freight rate two-way charges on any item returned to the Company's factory or any authorized distributor or service center, provided that prior written authorization for such return has been given by the Company.

This warranty shall not apply to any equipment which the Company determines to have become defective owing to mishandling, improper installation, alteration, negligence, inadequate maintenance, incorrect use, exposure to environmental conditions exceeding specifications, or any other circumstance not generally acceptable for equipment of a similar type.

The Company reserves the right to make changes in design without incurring any obligation to modify previously manufactured units.

No other warranties are expressed or implied, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. The Company is not liable for consequential damages.

83000001
